6877-1 Goreway Drive Mississauga, Ontario Canada, L4V-1L9 Tel: (905) 677-5533 Fax: (905) 677-5030 e-mail: rms@rmsinst.com http://www.rmsinst.com

## **RELEASE NOTES**

## PC300 CONTROL/INTERFACE SOFTWARE - Vers.1.04

- 1. Auto-start P/P modes are now also supported via serial port A. In previous versions, they were supported only via the parallel port.
- 2. The *data output port*, which had in the past always been assigned to serial port C, can now be assigned to either serial port C (default) or serial port A.
- 3. The default configuration file has been modified to ensure grid patterns, event markers, and time markers have an acceptable number of dots on.
- 4. Problem correction: In the *general configuration* form, modification of the *event marker* pattern would actually change the *time marker pattern* in PC300's own configuration. (The correct command and argument were sent out to the GP300.)